

General Purpose Transmitter



Features


- Measuring ranges from 100mbar to 600bar
- Absolute, gauge and sealed gauge
- Accuracy: $\pm 0.5\% \text{FSO (Typ.)}$, $\pm 0.25\% \text{FSO}$
- Calibrated and temperature compensated
- Stainless steel pressure sensor
- Variety of Pressure & Electrical connections
- Output 4...20mA, I²C, MODBUS, HART and other

Application

- Hydraulic and pneumatic
- Machine building
- Pumps
- Chemical industry

All specs are subject to change without notice

General Purpose Transmitter



All specs are subject to change without notice

General Purpose Transmitter

MODBUS-RTU Protocol

Serial port setup:

Parity bit: N ; Data bits: 8; Stop bit: 1; Baud Rate: 9600;

CRC Check Polynomial: 0x4D01

The communication protocol can transfer the Signed Integer Arithmetic and also transfer the Floating-Point Arithmetic

1. Communication format:

Signed Integer Arithmetic output

A. Send Command (Read Data)

address	Function code	Data start bit (H)	Data start bit (L)	Data number (H)	Data number (L)	CRC16 (L)	CRC16 (H)
0X01	0X03	0X00	0X00	0X00	0X01	0X84	0X0A

B. Receive Command (Read Data)

address	Function code	Data length	Data (H)	Data (L)	CRC16 (L)	CRC16 (H)
0X01	0X03	0X02	0X00	0X01	0X79	0X84

C. Send Command (Modify Data)

address	Function code	Data start bit (H)	Data start bit (L)	Data (H)	Data (L)	CRC16 (L)	CRC16 (H)
0X01	0X06	0X00	0X00	0X00	0X02	0X08	0X0B

D. Receive Command (Modify Data)

address	Function code	Data start bit (H)	Data start bit (L)	Data (H)	Data (L)	CRC16 (L)	CRC16 (H)
0X01	0X06	0X00	0X00	0X00	0X02	0X08	0X0B

E. Return of abnormal response

address	Function code	Abnormal Code	CRC16 (L)	CRC16 (H)
0X01	0X80+Function code	0X01 (Illegal function) 0X02 (Illegal address) 0X03 (Illegal data)		

Integer supported commands and meaning of command

Function code	Data Offset (Decimal)	Data number	byte	data area	meaning of command
Read area of Integer Arithmetic					
0X03	0	1	2	1-255	Slave Address
0X03	1	1	2	0-1200 1-2400 2-4800	Baud Rate

				3-9600 4-19200 5-38400 6-57600 7-115200	
0X03	2	1	2	0- No check 1- ODD 2- EVEN	0- No check 1- Odd check 2- EVEN check
0X03	3	1	2	0- Kpa 1- Mpa 2- Ma 3- % 4- InH2o 5- Fth2o 6- MmH2O 7- MmHg 8- PSI 9- Bar 10- Mbar 11- Kg/cm2 12- Pa 13- Torr 14- Atm 15- 16- M 17- Cm 18- Mm 19- inHg 20- mmHg 21- Mh2O 22- °C	Pressure Unit
0X03	4	1	2	0-#### 1-#### 2-#### 3-#### 4-####	Decimal point
0X03	5	1	2	0-30	Filtering Coefficient
0X03	6				
The above is operation of Integer Arithmetic					
Floating-Point Arithmetic read area					
Function code(Hexa)	Offset address (Decimal)	length	byte	Data area	Remarks

All specs are subject to change without notice

General Purpose Transmitter

decimal)					
0x03	22-23	2	4	4 byte	Pressure measurement
0x03	24-25	2	4	4 byte	Master variable of Pressure offset
0x03	26-27	2	4	4 byte	Range minimum of Pressure Transmitter
0x03	28-29	2	4	4 byte	Range maximum of Pressure Transmitter
0x03	30-31	2	4	4 byte	Range minimum of Pressure Sensor
0x03	32-33	2	4	4 byte	Range maximum of Pressure Sensor
0x03	38-39	2	4	4 byte	PTT 00 measured value
0x03	42-43	2	4	0-1.00000	Gain coefficient of main variable of pressure
0x03	166-167	2	4	4 byte	Zero clearing of Pressure Transmitter
The above is Floating-Point Arithmetic read area					
0x06 Function code Modify data					
0x06/0x10	0	1	2	1-255	Modify slave address
0x06/0x10	1	1	2	0-1200 1-2400 2-4800 3-9600 4-19200 5-38400 6-57600 7-115200	Modify Baud Rate
0x06/0x10	2	1	2	0- NO check 1- ODD 2- EVEN	Modify Check mode
0x06/0x10	24-25	2	4	4 byte	Zero offset value: Pressure value-measured value+Zero Offset value
0x06/0x10	166-167	2	4	4 byte	Zero clearing value of Pressure Transmitter
SAVE					

0x06	65535	1	2	0- Save to user zone	Write this address to 0, save the data to the user area and save the power off. If you do not send the power down save instruction, then modify the data off the electricity loss.
0x06	65533	1	2	Password service area	Address, checksum, baud rate modification without password, and other data changes should first write to this address, data 0x1234 is allowed to modify.
0x06	65532	1	2	0-Go back to Factory calibration status	The user writes this address to 0 to restore the factory data. It is all data recovery. Both the user setting data and the calibration data will be restored to the factory status.

For the transmission of floating-point Arithmetic, refer to the provisions of the MODBUS-RTU protocol regarding the transfer of multi byte floating point Arithmetic.

Read the pressure command, for example: (HEX)

Tx: 01 03 00 16 00 02 25 CF

01 slave address,

03 Function code,

00 16 Offset address,

00 02 Data number

Rx: 01 03 04 BE 40 E6 12 15 A2

01 slave address

03 Function code

04 Bytes

BE 40 E6 12 (0-188378, IEEE 754 Standard for Floating-Point Arithmetic)

Note the distinction between the data in the protocol, such as the offset address 22 (Decimal), and the Hexadecimal notation of 16. Note the difference.

All specs are subject to change without notice

General Purpose Transmitter

STORAGE

If the complex must be storage before use, please keep dry and repaired.

Do not leave outdoor.

Device is strongly sensitive to humidity hence avoid to store where relative humidity is more than 90%

STORAGE TEMPERATURE: $-30^{\circ}\text{C} \div +70^{\circ}\text{C}$

RELATIVE HUMIDITY: max 90% @ $+40^{\circ}\text{C}$

MAINTENANCE

Maintenance of transmitter must be done compulsory in factory. We recommend every 5 years to send back transmitter for calibration check and inspection.

WARRANTY

Device is covered by 24 months after installation or max 36 months after delivery.

In case of service the transmitter must be sent back to factory for inspection.

WARNINGS

CAUTION

Do not drop or hit the transmitter. The sensor is fragile and may break from sudden shock.

When transporting the transmitter, use the original shipping box from Electronsistem.

NOTE


Keep the transmitter dry and clean.

Do not remove the transparent transport protection caps before you are ready to install the transmitter.


General Purpose Transmitter

INSTALLATION

1. Remove the transport caps when you are ready to install the transmitter. Check o-ring is clean without dust and properly assembled.
2. Install the transmitter to the mechanical coupling and tighten gently by hand. Then use a wrench to tighten the connection. Use a sufficient force to achieve a tight installation (recommended 10-15Nm) . The system must be leak-free for accurate measurement.
3. Prepare and fix the cable with some cable ties in order to avoid stress on the connector of the sensor. Use a cable with a suitable outdoor IP67 connector for your installation (straight or angled)




4. Connect the output port checking the correct polarization of the connector. Do not rotate the cable before the crown of the cable is completely fixed!



All specs are subject to change without notice

General Purpose Transmitter

5. Turn firmly the rotating crown of the cable at max 0.4Nm



DISCLAIMER NOTE:

While we provide application assistance it is up to the customer to determine the suitability for its use.

Specification may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However we assume no responsibility for its use.

The quality of ElectronsistemMD products is guaranteed by a Quality, Safety and Environmental management system certified by DNV according to ISO 9001, ISO 18001 and ISO 14001. Electronsistem MD works in partnership with its customers in designing customized executions in order to meet specific requirements, please contact us.

All specs are subject to change without notice